



USER MANUAL

DEFROSTING TRAY

USE & CARE SUGGESTIONS

1. Dispense neutral detergent on a soft cloth or sponge.
2. Can be cleaned by using dishwasher.
3. Wash the defrosting tray with a soft cloth or sponge soaked in neutral detergent before use.
4. Do not use steel mesh, acidic/ alkaline detergent, or abrasive cleaning powder, etc., to clean the defrosting tray.
5. Do not soak the defrosting tray in water for cleaning.
6. Do not use sharp metallic objects in conjunction with the defrosting tray.
7. Do not use the defrosting tray in microwave oven as it may get damaged or cause the microwave oven to malfunction or start a fire.

DEFROSTING

Place the ingredients on the defrosting tray and defrost them naturally. No need to heat them.

FREEZING

Put fish, meat or other ingredients into a plastic bag, and put them on the defrosting tray in the freezer.

SUGGESTIONS

1. Defrosting speed is related to the contact area of the food, please put the food flat on the defrosting tray with as much surface area touching the tray as possible.
2. Quickly rinse defrosting tray with warm water before defrosting, the defrosting time will be shorter. When defrosting tray is being used continuously, washed it with warm water so it can be restored to normal room temperature quicker.